## Skycamp 2.0/Skycamp Mini - Insulation Tent

The Insulation Tent adds an extra layer of insulation, blocks cold drafts of air, helps retain body heat inside your tent, and provides a cozy and warm feeling inside your Skycamp.

Please follow these instructions for an optimal installation.

- **STEP 1:** Take the Insulation Tent out of its bag and spread it open inside your RTT.
- **STEP 2:** Locate the two large zippers that constitute the front door of the Insulation Tent and place them in front of your RTT entrance.
- **STEP 3:** There are 6 black fabric loops on the inside of your Skycamp/Skycamp Mini hard shell: 1 on each corner, and 2 (1 for Skycamp Mini) on the top middle behind your skyview window. Start by connecting the hooks of the Insulation Tent on the two bottom corners of the hard shell, and then make your way up, connecting all 6 hooks.
- **STEP 4:** Clip the plastic hooks of the Insulation Tent's middle section onto the round aluminum bar in the middle of the RTT, starting from the center and working outwards.
- **STEP 5:** Find the 2 remaining fabric loops located on each corner of the aluminum extension panel, and attach the Insulation Tent's hooks.
- **STEP 6:** Tuck the Insulation Tent's excess material along and under the sides of the Skycamp's mattress to prevent any cold drafts of air coming inside.
- You're done! If you'd like to keep the windows or front door of the Insulation Tent open, you can roll them back and attach them in place.





**IMPORTANT:** Be sure to unclip the Insulation Tent from the round aluminum bar and extension panel before closing your RTT. Failing to unclip the insulation tent could result in tearing damage.

If you have any questions, please contact us at support@ikamper.com

